

FIG. 1




FIG. 2

2/15




FIG. 3




FIG. 4

3/15




FIG. 5




FIG. 6




FIG. 7

4/15




FIG. 8




FIG. 9




FIG. 10

5/15




FIG. 11




FIG. 12





FIG. 16

7/15





FIG. 17





FIG. 18





FIG. 19





FIG. 20

8/15

SEND

File	disney.042902
Address	address book
Message	Text
SELECT	CANCEL

Message

- text
- voice recognition

Back Home Select Forward

FIG. 21

PAYMENT

Pay	Today
Method	VISA
Amount	\$4.95
Password	*****
SELECT	CANCEL

Payment

- today
- date

Back Home Select Forward

FIG. 22




FIG. 23




FIG. 24




FIG. 25

10/15




FIG. 26






FIG. 27

11/15



12/15




FIG. 30




FIG. 31

13/15




FIG. 32




FIG. 33

14/15




FIG. 34




FIG. 35




FIG. 36

15/15




FIG. 37




FIG. 38